





SW2

MOTOR FAZ AKIMI				BEKLEMEDE MOTOR AKIMI		ÇALIŞMA İZİN SEÇİMİ	
1	2	3	4	SW2	FAZ AKIMI *	SW2	ÇALIŞMA
ON	ON	ON	ON	ON	50	ON	İZİNLI(ENABLED)
OFF	ON	ON	ON	OFF	100	OFF	ENB. INPUT İLE BELİRLENİR
ON	OFF	ON	ON				
OFF	OFF	ON	ON				
ON	ON	OFF	ON				
OFF	ON	OFF	ON				
ON	OFF	OFF	ON				
OFF	OFF	OFF	ON				
ON	ON	ON	OFF				
OFF	ON	ON	OFF				
ON	OFF	ON	OFF				
OFF	OFF	ON	OFF				
ON	ON	OFF	OFF				
OFF	ON	OFF	OFF				
ON	OFF	OFF	OFF				
OFF	OFF	OFF	OFF				



SW1

MICRO STEP				PULSE ÇALIŞMA BİCİMİ		CC/CCW MODE	
1	2	3	uStep	SW1	PULSE MODE	PULSE	DIR
ON	ON	ON	2	ON	CC/CCW MODE		
OFF	ON	ON	4	OFF	PULSE/DIRECTION		
ON	OFF	ON	8				
OFF	OFF	ON	16				
ON	ON	OFF	32				
OFF	ON	OFF	64				
ON	OFF	OFF	128				
OFF	OFF	OFF	256				



Itemref	Quantity	Title/Name, designation, material, dimension etc	Article No./Reference	
Designed by	Checked by	File name	Date	Scale
			12/07/2016	
mSTEP KULLANMA KILAVUZU		ELDES ELEKTRONIK	Edition	Sheet
			2	1/1